



COSMOS OUTDOOR TV PRODUCT MANUAL







**Evervue Standard
TV Remote**
(RMS50)




Zepp Remote
(RM-ZEPP-BLACK)




Bolts and Tools



Audio Streamers



Extension Cord



Power Supply
(COSAC-PS)

When the Cosmos is installed outdoors or in a moisture-prone environment, it **MUST** remain connected to power at all times to ensure its internal ventilation system operates properly and prevents moisture buildup. Failure to do so may result in the warranty being voided.

The Cosmos must be installed with the rain cap and in a landscape position. If the rain cap is not installed, the warranty may be voided. Additionally, if the Cosmos is not installed in a landscape orientation, the warranty may be voided.

The Cosmos is **NOT** designed to be installed on moving vehicles such as cars or trucks. Installation on moving vehicles may void the warranty.


Please note that the Cosmos is weather-resistant but not fully waterproof and cannot be submerged in water.

As part of our unique Damage Free Delivery Guarantee, it is important that you inspect your product immediately upon delivery for any transportation damages. Examine the item for any visible damages and review the contents of the package within 24 hours of receipt. If you find any damages or if any parts are missing, please refer to the guidelines in the attached PDF. Report any issues by emailing shipping@evervue.com with your name, order number, and photographs of the damage.



PARTS


- | | | | |
|----------|------------------|----------|------------------------------------|
| A | Rain/Sun Cap | D | Heat Strengthened Anti Glare Glass |
| B | Extra thin Bezel | E | Wide Angle Infrared Receiver |
| C | Audio Streamers | | |

NOTES

- | | | | |
|----------|---|----------|---|
| F |  | G |  |
| | Sun Cap
Screws | | Audio Streamer
Screws |

CLOSE-UP



**PARTS**

- H** VESA Compatible for Mounts/Brackets
- I** Warm Air Outlet for Cooling System
- J** Power, HDMI, USB, Audio Compartment
- K** Stainless Steel, Easy Access On/Off Button
- L** Direct Wall Mount Openings
- M** Set Top Box Compartment
- N** Kensington Lock Opening
- O** Cool Air Inlet




BUTTONS

A	Power IR Learning key	K	Enter / Mouse Left
B	Mouse ON/OFF	L	Long press to turn ON/OFF the backlit
C	Backspace	M	Open Google Voice Assistant
D	Navigation keys (Up/Down/Left/Right)	N	Volume up (+)
E	Home return / Mouse right	O	Next
F	Volume down (-)	P	Mic
G	Play / Pause	Q	Full keyboard
H	Previous	R	Touch panel
I	Indicator	S	Charging Interface
J	Menu	T	ON/OFF


HOW TO INSTALL THE GOOGLE ASSISTANT



1 Open the play store and search for Google.




2 Download Google. Then tap the icon on the home screen.



3 Control the app with either your voice or the keyboard on the remote.

(Configuration depending on market)




BUTTONS

- A** USB Port
- B** USB Port
- C** Micro SD Card
- D** Ethernet Cable
- E** Audio Port
- F** HDMI Port
- G** Power Port




WHAT CAN YOU DO WITH THIS REMOTE ?

- Change the brightness and color of the screen.
- Change the HDMI input
- Increase the audio volume of the T.V.
- several more advanced settings




1 Check the Items After Receiving

Upon receiving your order open the crate and inspect the content. **Damages must be reported within 24 hours.**




2 Set up your Mount

Before setting up your Cosmos Outdoor TV, set up your mount first. A separate manual is provided for each of our Cosmos Mounts.




3 Attach the Cosmos

Attach the cosmos outdoor tv to your mount. Check the separate mount manual.




4 Remove the compartment covers

Use the allen key to remove the base protectors at the back of the Cosmos Outdoor TV.




5 Plug the Cables

Plug the power cord to the power port located at the smaller compartment at the back of the Cosmos Outdoor TV.




6 Install the Sun Cap

Take the sun cap and attach it on top of the Cosmos Outdoor TV using the allen key included in the package.




7 Install the audio streamers

Attach the Audio Streamers on both the bottom left and bottom right backside of the Cosmos Outdoor TV.




8 Finished

Done. Your cosmos is installed and ready for set up.




1 Turn on Cosmos

Either Press the power button on the right side of the TV or on the remote to turn the cosmos outdoor TV on.



2 Connect to the internet


Go to "Settings" and choose "network".



3 Connect to the internet


Find your wi-fi name on the list of networks that would pop up and enter your password.

INSTALLING APPS





Option 1 Google Play Store

Find the desired app on the Google Play Store. Download and install it on your device.



Option 2 Install APK

Download your APK online. Find it on the "File Manager" and double click it to install.

ONLY APPLICABLE FOR THE BRUSHED STAINLESS STEEL

With this special buffer you make stainless steel look as new again in minutes.

Important Notes:

1. Please press firmly with buffer in one sweeping motion in the same direction as the structure and grain of the stainless steel.
2. DO NOT make circular movements.
3. DO NOT go against the grain and structure of the stainless steel.

So entferne man wirkungsvoll kleinere Kratzer aus dem Edelstahlrahmen. Mit dem in der Lieferung enthaltenem Pflegeschwamm können gegebenenfalls kleinere

Bitte beachten:

1. Immer und ausschließlich in gleichmäßig fortlaufender Richtung mit konstantem Druck der Struktur des Stahls folgen.
2. Niemals versuchen in wechselnden Richtungen von links nach rechts, oben nach unten oder in kreisenden Bewegungen die Stahlfläche zu bearbeiten. Nur wenn Sie die Anweisung (wie in Position Nummer 1. beschrieben) strikt befolgen, werden Sie ein sichtlich zufriedenstellendes Resultat erzielen.

Avec ce tampon spécial, donnez un nouveau look à votre cadre en acier inoxydable en quelques minutes

Important:

1. Appuyez fermement avec le tampon avec un mouvement rectiligne dans la même direction que les lignes de structure de l'acier inoxydable.
2. NE PAS faire de mouvements circulaires.
3. NE PAS aller à l'encontre des lignes de structure de l'acier inoxydable.

Volg de onderstaande instructies en uw RVS is weer in enkele minuten als nieuw.

Belangrijk:

1. Wrijf stevig en met één beweging in de richting van de structuur van het RVS.
2. Maak geen cirkelvormige bewegingen. Wrijf niet tegen de structuur richting in.

使用这种特殊的百洁布会让您的不锈钢立即焕然一新。

重要信息：

1. 请顺着不锈钢本身的结构与纹理单向紧按百洁布进行擦拭（不可交叉擦拭）。
2. 请勿以打圈方式擦拭。